

RoscoGrip™ Strips Installation Instructions



Step 1 - Prepare The Surface

Use an appropriate glass or multi-purpose cleaner to thoroughly clean the surface, ensuring it's free of dirt, dust, or anything else that may inhibit the adhesion process. Dry thoroughly with a lint-free cloth.



Step 2 - Stick Into Place

Cut a RoscoGrip Strip that is a few inches longer than the area you want to cover. Slowly peel a small amount of the release liner off the back, and then press the exposed adhesive onto the surface. Detach to re-position if needed. Slowly peel the rest of the release liner away and press and smooth the RoscoGrip Strip as you go.



Step 3 - Smooth Out Wrinkles/Bubbles

The medium-tack adhesive should allow you to easily detach and reattach the RoscoGrip. If there are wrinkles and bubbles in your application, detach the nearest edge to the bubble/wrinkle and then pull the RoscoGrip taut as you smooth the material out.



Step 4 - Trim To Fit

Using a sharp matte knife – carefully cut the excess RoscoGrip away. Save excess pieces to fill in any small areas the initial RoscoGrip Strip did not cover.



Step 5 - Removal

Once the RoscoGrip Strip has served its purpose, you can easily remove it by simply peeling the RoscoGrip off of the surface it has been applied to.

Disclaimer: While the RoscoGrip adhesive should be safe to use on most surfaces and finishes, it is up to the end user to test the product beforehand to make sure the adhesive does not negatively affect the surface it's being adhered to.

